

MAGNIFIER LAMP

NO.: 8093B

Thank you very much for purchasing our Magnifier Lamp. The Magnifier Lamp is ideal for precise work in home, office and workshop as well as a lot of other important places. Before using the Magnifier Lamp, please read the following instructions.

1. Important data:
 - A. Magnifier: Ø100mm diameter, 3 diopter + 12 diopter
 - B. Voltage: AC 110-120V 50/60Hz
 - C. Bulb Type: 12W G10q
2. How to use:
 - A. Before use, remove all packing from around the lamp.
 - B. Put the lamp on the horizontal table.
 - C. Insert the plug into a conveniently located electrical socket.
 - D. Switch on using the ON/OFF switch located on the surface of the base.
 - E. To place the head in the desired position.
3. Replacing the Tube:
 - A. Always switch off, remove the plug from the mains supply and allow the lamp to cool before changing the tube.
 - B. Rotate the head so you can see the underside. Using a suitable screwdriver remove the five small screws that secures the diffuser to the head of the lamp.
 - C. Remove the diffuser and place safely to one side.
 - D. Remove the tube from the head and gently unplug the 4-pin connector-discard the old tube safely.
 - E. Gently push-fit the 4-pin connector onto the new tube ensuring it is pushed on fully.
 - F. Position the new tube into the head, replace the diffuser and tighten the 5 screws to hold it in place.
4. Caution for safe using:
 - A. Indoor use only.
 - B. Environment temperature:-20°C~40°C.
 - C. Humidity: ≤95%.
 - D. Never disassemble the magnifier lamp unless you are a qualified electrician.
 - E. Plug must be taken out while repairing the magnifier lamp.
 - F. Never leave the lens unattended in direct sunlight or where light can shine through it. This constitutes a fire hazard.
 - G. If the external flexible cable or cord of this magnifier lamp is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
5. FCC warning statement

This device complies with Part 18 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.